

KADZAMA

TECHNOLOGY FOR SUCCESS

Melter 5 kg

Manual



This manual is designed for study the main technical characteristics, operating principle and rules of technical operation of melter 5 kg.

Before use carefully read the instructions below!

Improper use of the equipment can be a source of danger. By starting work with the device you confirm that you are fully acquainted with this manual and understood the rules of operation of the device.

KADZAMA appreciates your purchase and wishes you a pleasant work experience.

1 — Purpose of the device

Melter 5 kg is designed for heating and tempering chocolate.

2 — Specifications

Supply, [V] / [Hz]	220 / 50
Power, [kW / h]	0.2
Maximum loading capacity, [kg]	5
Minimum loading capacity, [kg]	3
Material	Stainless steel
Heating range, [°C]	20 — 50
Dimensional size (L x W x H), [mm]	430 x 240 x 175
Weight (unpackaged / in package), [kg]	7 / 7,5

3 — Configuration

Melter 5 kg — 1 pc.

Lid — 1 pc.

Manual — 1 pc.

Warranty card — 1 pc.

4 — Safety measures

4.1. Melter 5 kg is an electric appliance with a certain danger potential. When connecting the device to the electric grid, take all necessary precautions to avoid electric shock.

4.2. Melter 5 kg must be connected to the power supply and operated only by trained personnel.

4.3. It is not allowed to operate the melter 5 kg in the absence of electrical grounding («E» wire).

4.4. Melter 5 kg should be used only for its intended purpose.

4.5. Use and store the melter 5 kg in a place out of reach of children

4.6. Do not leave the melter 5 kg switched on without supervision for a long time.

4.7. Do not operate the melter 5 kg with wet hands.

4.8. Do not allow liquids inside the melter 5 kg through the ventilation.

4.9. Do not use the melter 5 kg at ambient temperatures below 10°C and above 40°C, and relative humidity above 80%.

4.10. When transporting the melter 5 kg at sub zero temperatures, prior to first use it should be kept at room temperature for at least 1 hour.

4.11. Any maintenance should be carried out when the melter 5 kg is disconnected from the power supply!

4.12. Repair or disassembly of the melter 5 kg may only be provided with the assistance of qualified personnel of KADZAMA.

5 — Before start

5.1. Remove the packaging.


5.2. Set the melter 5 kg on a flat hard surface, providing easy access to controls.

5.3. If the melter 5 kg was at sub zero temperatures for a long time, allow it to warm up to room temperature before turning it on.

5.4. Empty the container and load at least 3 kg of chocolate into it.

5.5. Make sure that the power supply is correct and that the power source is properly grounded. Plug the equipment into a 220V.

6 — Control panel description



1 — Power ON / OFF button;

2 — Temperature display: it shows the current temperature value as well as the set temperature value if any button is pressed;

3 — Temperature deviation indicator (**▲** | **■** | **▼**). Indicator (**▼**) signals that the current temperature is less than the set one. Indicator (**▲**) signals that the current temperature exceeds the set one. Indicator (**■**) signals that the current temperature matches to the set one;

4 — Temperature set value indicator (**SV**). To check or change the current temperature set value (**SV**), press any key on the front panel once, while the set value indicator (**SV**) is on and the set value blinks;

5 — Unit of measurement indicator (**C°** | **F°**);

6 — Control output indicator (**OUT**). The indicator lights up when the heating elements are activated;

7 — The (**MODE**) key is used to enter / exit adjustable parameters mode and save the set values;

8 — Settings keys (**⏪** **⏩** **⏴**) are used to change setting values.

7 — Exploitation

IMPORTANT! For correct equipment operation it is necessary to maintain a room temperature from 18°C to 25°C. Otherwise, the heating system will show a result higher, than the permissible one (we also draw your attention to the fact that deviation from temperature standards in the room can affect the quality of the product, since in most cases its properties also depend on the environment).

7.1. Turn on the melter with the **ON / OFF** button. The controller display must light up.

7.2. Temper the chocolate. There are many methods of tempering the chocolate with a steam table. The easiest tempering method is determined based on the working conditions and the skills level of the specialist. There are three ways to prepare chocolate below.

7.2.1. Method A — Sowing stable crystals:

— Heat up the chocolate to 42-45°C (or other temperature recommended by chocolate manufacturer);

— Change the temperature value on the controller to fit the working temperature of the chocolate (33°C or the value recommended by the chocolate manufacturer);

— Add 20-30% of chocolate pieces to the heated chocolate mass;

IMPORTANT! *The pieces must be tempered and the same size. The larger the pieces, the fewer you need.*

— Mix well until the pieces are completely dissolved. The pieces should melt completely at the moment the set working temperature is reached;

IMPORTANT! *If the pieces are dissolved at a temperature of 34°C and above, then there is a big chance that the chocolate won't contain the required quantity of stable crystals. If the set temperature is reached, and the pieces are not melted, then cover the container with a lid and repeat stirring after 10-15 minutes until the pieces are completely dissolved.*

— Collect the probe and check the quality of the tempering;

— Upon finishing the work, set the temperature to 40-50°C, cover with a lid;

— To start the work, repeat all the steps again.

7.2.2. Method B — Classic tempering:

— Heat up the chocolate to 42-45°C (or other temperature recommended by chocolate manufacturer);

— Change the temperature value on the controller to fit the working temperature of the chocolate (33°C or the value recommended by the chocolate manufacturer);

— Remove a bit of chocolate from the container and pour it on a marble or granite table;

— Methodically mixing chocolate on a cold table surface, lower the temperature to 26-27°C. The look of the chocolate can also serve as an indicator of a successful result: the surface of the

mass should change its gloss to matte, the chocolate becomes much thicker.

— Collect the chocolate in a cup and return it to the tempering container. Mix thoroughly. The temperature of the chocolate mass must be within the working temperature range of the chocolate;

— Collect the probe and check the quality of the tempering;

— Upon finishing the work, set the temperature to 40°C, cover with a lid;

— To start the work, repeat all the steps again.

7.2.3. Quick start:

— For a quick start the chocolate in the container must be already tempered. This technique is suitable if you plan to continue working in the near future (for example, the next day or in 1-2 days);

— At the end of the working day it is necessary to set the temperature on the controller to 36-37°C (depending on the temperature in the room);

— Cover the container with a lid and leave it until the the next working day;

— Set the working temperature to 33°C, mix the formed chocolate crust well with the warm chocolate on the bottom until smooth (the temperature should not be higher than 33°C);

— Collect the probe and check the quality of the tempering;

— Upon finishing the work, set the temperature to 36-37°C (depending on the room temperature).

7.3. Recrystallization of chocolate.

Recrystallization of chocolate is a process in which a mass of chocolate, being at the same temperature (for example, 33°C), changes its viscosity to a more viscous one. After 1-2 hours of working with the prepared chocolate, the recrystallization process begins (appears as increased viscosity of the product). In order to return the chocolate to its normal state, it's enough to evenly heat it with a heat gun to a temperature of 33.5-34°C (or add hot chocolate with a temperature of 37-50°C to it). The volume of added chocolate is determined empirically, based on temperature conditions and the degree of recrystallization.

IMPORTANT! *When adding hot chocolate, the working volume in the bowl must be thoroughly and constantly mixed for uniform temperature distribution, and the temperature must also be continuously monitored with an external temperature measuring device (for example, a pyrometer).*

7.4. Adding chocolate to the melter.

It's much more efficient to keep the melter filled at least half of the maximum load. This allows you to ensure stable and long-term work with chocolate. In order to add chocolate to the bowl and not out-temper it, it must be hot (37-45°C). It is also necessary to gradually and well mix the mass and control the temperature with a pyrometer (it should not exceed 33°C).

8 — Troubleshooting

8.1. Malfunctions checklist for melter.

If your melter does not start, follow these steps:

— Check the power supply cable, it must be undamaged and connected to the equipment correctly;

— The socket where the equipment is connected has a right voltage for the power supply parameters specified in the technical characteristics of the connected equipment (Your building may be completely de-energized, or the circuit breaker responsible for this socket is turned off in the junction box of the room);

— The equipment plug is connected to the socket correctly and completely;

— Switch on the equipment, make sure that the indicator on the controller lights up. The controller will display the actual temperature, which after a while will begin to rise up to the set one, it can be adjusted with the «up» and «down» keys;

— When turning on check all the inner walls of the equipment with your hand, they should begin to heat up. To check the uniformity of heating, you can stick a piece of masking tape on each of the walls and use a pyrometer to measure the temperature after turning on the bowl and letting it reach the set temperature (**remember that the pyrometer cannot correctly measure temperature from reflective metal surfaces**);

— If the bowl still continues to heat up or there are other deviations after reaching the set temperature, it's recommended to do the initial setting of the controller;

— If all of the above conditions are met, and the equipment cannot be restored to work, please inform the KADZAMA manager about all the steps you have done for further consultation.







Initial parameter setting:

First you must unlock the settings, to do this use the relevant section below. Then turn on the device, press the **MODE** button on the controller and hold it until the **PAr2** parameter appears on the screen, release the button.


Control:

Using the **MODE** button select the code, change the value with the «up» button, press the **MODE** button again to save the value.

A list of parameters and values for correct operation:

Code	Meaning	Note
 <p>In-t</p>	 <p>dPtL</p>	Temperature sensor
 <p>Unl t</p>	 <p>C°</p>	Temperature unit
 <p>L-Su</p>	 <p>20</p>	Lower temperature level

<p>H-Su</p>	<p>50</p>	<p>Upper temperature level</p>
<p>o-Ft</p>	<p>HEAt</p>	<p>Operating mode (heating / cooling)</p>
<p>C-nd</p>	<p>PI d</p>	<p>Regulation type</p>
<p>oUt</p>	<p>SSr</p>	<p>Solid state relay control selection</p>



Operating mode
(cyclic / phase)





After entering all the parameters, press the **MODE** button again for 2-3 seconds to exit the setting mode, the temperature will be displayed on the controller.

8.2. Block / exit block.

Turn on the device, press the **MODE** button and hold it until you see the **PAr2** parameter on the screen, release it.


Control:

Using the **MODE** button select the code, change the value with the «up» button, press the **MODE** button again to save the value. Find the «LoC» parameter using the «up» button and select «LoC2» (select the **OFF** parameter to exit), press the **MODE** button.

Code	Meaning	Note
 <p>TC4S 8.8.8.8 SV °F °C AL1 AL2 OUT MODE << >> <></p> <p>LoC</p>	 <p>TC4S 8.8.8.8 SV °F °C AL1 AL2 OUT MODE << >> <></p> <p>LoC2</p>	<p>Block activation</p>
 <p>TC4S 8.8.8.8 SV °F °C AL1 AL2 OUT MODE << >> <></p> <p>LoC</p>	 <p>TC4S 8.8.8.8 SV °F °C AL1 AL2 OUT MODE << >> <></p> <p>oFF</p>	<p>Выключение функции блокировки</p>

If all of the above conditions are met, and the equipment cannot be restored to work, please inform the KADZAMA manager about all the steps you have done for further consultation.



8.3. Exit the test mode.



If you see **TEST** on the screen while working with the bowl, this means that the controller is now in test mode.

Press the **MODE** button to select the **KEY** parameter, then press the «up» arrow and the **MODE** button at the same time.

Press the «up» arrow until the display shows **END**.

Code	Meaning	Note
 <p style="text-align: center;">KEY</p>	 <p style="text-align: center;">End</p>	<p>End of test mode</p>

Turn off the device, the controller should exit the test mode.

9 — Maintenance and care

9.1. During the work keep the melter 5 kg clean. Any maintenance should be carried out when the device is disconnected from the power supply and cooled to room temperature.

9.2. It is allowed to wipe the body with a clean, wet sponge or cloth.

9.3. Wash the inside of the bowl (if necessary) with warm soapy water first, and then rinse several times with clean water and wipe dry.

9.4. If the equipment won't be used for a long time (more than 2 days), it is necessary to disconnect it from the power supply and clean it thoroughly. Repeat steps **9.2** and **9.3** before putting the bowl to work.

10 — Warranty

The warranty period (as well as the terms of warranty service) are specified in the warranty card.

11 — Certificate of acceptance

Melter 5 kg complies with stated specifications and is recognized as serviceable.

kadzama.com

sales@kadzama.com

Meets certification requirements

CE EAC